


FIG. 1

100






FIG. 2

3/17

121




FIG. 3

FIGURE 4-2000-222222




FIG. 4

5/17




FIG. 5





FIG. 6







9/17

500




FIG. 9




FIG. 10







FIG. 11







**FIG. 14**




FIG. 15






FIG. 17



SELECTIONS FROM  
MENU OR SCREEN

QUICK TIP: PRESS  
ANIMATION TO HEAR AND  
SEE DEMO

ANIMATION

VOICE

FIG. 18

MORE INFORMATION

USER ICON

AUDIO SYSTEM RADIO CASSETTE CD VIDEO TV WEATHER BAND

RADIO STATIONS: XX LOS ANGELES, XX SANTA ANA STATIONS  
X IRVINE  
SAVE AREA SETTINGS YES NO

SELECTION BEING PLAYED:

XX SONG, XX ALBUM 1245

1247 1249

YOU ARE  
LISTENING  
TO:

1271



1273

10 COUNTRY: FM100.7

FM102.9 AM103.5



1275

AM79.00

FM89.9 FM91.2 AM98.6 AM107.0



5 ROCK: FM89.3 FM98.1

AM990

FM102.7 FM107.90



2 CLASSIC: FM91.4

FM96.4

QUICK TIP: SCROLL FOR  
XX MORE STATIONS  
USE MOUSE CONTROLS  
OR PRESS TO SELECT

QUICK TIP: ANTENNA  
IS ACTIVATED BY  
RADIO AND TELEPHONE,  
BOTH MUST BE  
SWITCHED OFF TO  
LOWER ANTENNA

SET FOR: DRIVER PASSENGER 1 2 3 4 5

1247 1249

ON OFF VOLUME CONTROL

FADER CONTROLS FRONT BACK

LEFT RIGHT LEFT RIGHT

MOVE SPEAKERS FOR  
DESIRED SOUND  
EFFECTS

PRESS EFFECT THEN

SPEAKER

ROCK

SURROUND

MOVIE

ETC.

YOU  
ARE  
HERE



1251



1253



1255

1257

RESTORE SETTINGS

SMART AUDIO

STEREO

MORE INFORMATION

AUTO RADIO

DOLBY

SAVE PREFERENCES

DIGITAL  
ENCODED

1207

1205